


## Semiautomatic welder SPARTUS® ProMIG



**200 PFC**



**User's manual**



## WELDING EQUIPMENT SUITABLE FOR TODAY'S NEEDS

### **Thank you for purchasing our product!**

You have made a right choice. Plasma welding and welding processes are carried out in difficult conditions that expose welding equipment to extreme tests of its strength. Only high quality equipment can ensure required reliability and performance during realization of the above-mentioned processes. SPARTUS® products are characterized by precisely such features: they are primarily reliable and durable, but they are also versatile. We listen carefully to clients' needs. Therefore, our offer covers such a wide assortment of products. Thank you very much for your trust in our company. We would like to invite you to familiarize yourself with the remaining products and offer at [www.spartus.info](http://www.spartus.info) or directly at a local distributor of SPARTUS® products.

## TABLE OF CONTENTS

<b>1. SAFE USE – HAZARDS ASSOCIATED WITH ARC WELDING AND PLASMA CUTTING</b> .....	<b>2</b>
1.1 General safety rules .....	2
1.2 Electric shock can kill .....	2
1.3 Welding arc radiation can be dangerous .....	3
1.4 Vapours and gases can be dangerous .....	3
1.5 Noise can be harmful .....	4
1.6 Fire or explosion hazard .....	5
1.7 Other hazards .....	6
1.8 Other informations .....	6
1.9 Symbols used in instructions .....	7
<b>2. ELECTROMAGNETIC FIELD (EMF)</b> .....	<b>7</b>
<b>3. ELECTROMAGNETIC COMPATIBILITY (EMC)</b> .....	<b>7</b>
3.1 General informations .....	7
3.2 Assesment of area .....	8
3.3 Methods of reducing emmissions .....	8
<b>4. CONFORMITY WITH STANDARDS</b> .....	<b>8</b>
4.1 CE marking .....	8
4.2 Rating plate .....	9
<b>5. GENERAL DESCRIPTION</b> .....	<b>9</b>
5.1 Purpose of use .....	10
<b>6. TECHNICAL SPECIFICATIONS</b> .....	<b>10</b>
6.1 Operation, storage and transport .....	10
6.2 Technical parameters of device .....	11
<b>7. INSTALLATION AND USE</b> .....	<b>12</b>
7.1 Proper cooling .....	12
7.2 Movement and handling .....	12
7.3 Description of construction .....	13
7.4 Connecting to power supply .....	14
7.5 Installation – MIG welding .....	14
7.6 Installation – TIG welding .....	17
7.7 Installation – MMA welding .....	18
7.8 Device control panel – using .....	18
7.9 User interface using .....	19
<b>8. MAINTENANCE</b> .....	<b>24</b>
<b>9. ENVIRONMENTAL PROTECTION</b> .....	<b>24</b>
<b>10. TROUBLESHOOTING</b> .....	<b>25</b>



### **IMPORTANT!**

*Before using this product, read the instruction manual in its entirety, with understanding. Keep the instructions for quick reference to it if necessary. Pay special attention to safety instructions provided for your protection. In the event of any points of misunderstanding instructions, contact your supplier or supervisor.*

# 1. SAFE USE – HAZARDS ASSOCIATED WITH ARC WELDING AND PLASMA CUTTING

Arc welding and plasma cutting are processes that can pose hazards for the operator and persons in his vicinity. The operator and his close surroundings are exposed, among others, to the risk of fire, explosion, electric shock, burning, as well as the risk of getting injured by moving parts of the device.

Once proper safety measures are provided, electric welding and plasma cutting are relatively safe processes. For this reason, it is crucial to strictly follow the valid OSH principles during welding operations.

The informations provided below do not release the operator from the obligation to follow the OSH rules that are binding in his plant/workplace.

## 1.1 GENERAL SAFETY RULES

Welding operators and persons working in the vicinity of the welding process should be made aware of the following hazards associated with arc welding. They should be made aware of protective measures as specified in relevant international and national standards and regulations.

### 1.1.1 Equipment condition and maintenance

- Check the technical condition of the device and accessories before starting to weld/plasma cutting. It is forbidden to use equipment that is unserviceable.
- Equipment damaged or defective should be immediately repaired or removed from service.

### 1.1.2 Operation and carrying

- Apply appropriate protective measures in the space around the zone, where welding operations are expected to be carried out.
- All equipment should be placed so that it does not present a hazard in passageways, on ladders or stairways, etc.
- Falling objects can cause injuries or kill. Protect device before accidentally falling.
- Welding equipment may be heavy (e.g. *wire*

*feeder fitted with spool and harness*). Care shall be taken during manual handling.

- To handle heavy elements, use hoists/trucks/transport equipment designed especially for this purpose. Make sure the weight of equipment to be handled does not exceed the admissible maximum lifting capacity of used hoist/truck/transport equipment.
- It is forbidden for unauthorized persons, especially children, to be in the vicinity of the device during its use.
- The device is not suitable for pipe defrosting.
- Device use non-compliant with its intended purpose is forbidden.

### 1.1.3 Training

- Only professionally trained and qualified personnel may install, operate, maintain and repair the device.
- For operators and their supervisors training is essential in: the safe use of the equipment; the processes; the emergency procedures.


## 1.2 ELECTRIC SHOCK CAN KILL



- Before starting to weld and during the welding process, the operator should insulate himself from the ground and the environment by means of dry and undamaged protective clothes. It is forbidden to work on wet ground.
- It is forbidden to touch SK sockets („+“ and/or „-“) when the device is in operation (*connected to a power supply source*).
- It is forbidden to touch live electric components of the device.

- Power supply must never be connected before the accessories of SK sockets/connectors are properly installed in the device.
- Use dry and undamaged welding gloves and protective clothing, in order to ensure proper insulation of the body. It is forbidden to touch with a bare hand any elements that are parts of an electric circuit.
- The operator must always make sure that there is a good electric connection of the return conductor to the element to be welded. The connection should be located as close to the welding zone as possible.
- Maintain the electrode grip, the welding torch, the chassis ground clamp, welding cables and the welding machine in proper technical condition that ensures safe operation. Damaged cable insulation should be replaced with new insulation.
- Never dip an electrode into water, to cool it down.
- When working above the floor level (at a height), use a safety harness to protect yourself against falling, in the case of potential electric shock.
- Exercise special caution, when using the device in small rooms or in rooms with elevated humidity levels.

### 1.3 WELDING ARC RADIATION CAN BE DANGEROUS



The arc generates:

- ultraviolet radiation (*can damage skin and eyes*);
- visible light (*can dazzle and impair vision*);
- infrared (*heat*) radiation (*can damage skin and eyes*).

Such radiation can be direct or reflected from surfaces such as bright metals and light coloured objects.

#### 1.3.1 Eye and face protection

- Use welder's helmet/shield with an appropriate filter to protect you face and eyes against sparks and welding arc radiation.
- The shield / helmet should provide eye and face protection against injuries that may result in welding spatters.
- Welding helmet/shield should be made in accordance with applicable standards.


#### 1.3.2 Body protection

- The body should be protected by suitable clothing in accordance with applicable standards.
- Use appropriate protective clothing made of durable and fire-resistant material, to ensure proper skin protection.
- The use of neck protection can be necessary against reflected radiation.

#### 1.3.3 Protection of persons in the vicinity of an arc

- Protect the remaining personnel present in the vicinity of welding works against negative impact of arc radiation and welding splatters. Warn them about the hazard resulting from exposure to the welding arc. In the vicinity of an arc, non-reflective curtains or screens should be used to isolate persons from the arc radiation. A warning, e.g. a symbol for eye protection, should refer to the hazard of arc optical radiation. Welder's assistants should also wear appropriate protective clothing.

### 1.4 VAPOURS AND GASES CAN BE DANGEROUS



Arc welding and allied processes produce welding fume which may pollute the atmosphere surrounding the work. Welding fume is a varying mixture of airborne gases and fine particles which, if inhaled or swallowed, constitute a health hazard.

The degree of risk is depend on:

- the composition of the fume;
- the concentration of the fume;
- the duration of exposure.

A systematic approach to the assessment of exposure is necessary, taking into account the particular circumstances of the operator and the ancillary worker who can be exposed.

Welding fume may be controlled by a wide range of measures, e.g. process modifications, engineering controls, methods of work, personal protection and administrative action.

First it is necessary to consider whether exposure can be prevented by eliminating the generation of welding fume altogether. Where this cannot be done, measures for reducing the quantity of welding fume generated should be investigated, after which the control of welding fume at source should be considered. The use of respiratory equipment should not be contemplated until all other possibilities have been eliminated. Normally, respiratory protective equipment should be used only as an interim measure. However, there cannot be a situation in which, in addition to ventilation, the use of personal protection is necessary.

#### 1.4.1 VAPOURS AND GASES. ADDITIONAL PRECAUTIONS

- Welding operations can involve generation of vapours and gases that are hazardous to health. Inhaling the vapours should be avoided. Keep your head away from vapours during welding operations. Ensure proper ventilation and/or mechanical welding exhaust draught to keep vapours and gases away from the breathing zone.
- When welding is carried out in a confined space, operators should only be permitted to weld when other persons, who have been instructed and who are able to react

in case of an emergency, are in the immediate vicinity.

- In closed rooms or in certain circumstances during outdoor operations, it may be required to use individual equipment for the protection of the welder's airways, e.g. a respirator. Additional safety measures are also required when galvanized steel is welded.
- Welding operations must not be performed in the vicinity of chlorinated hydrocarbons generated during degreasing, cleaning or spraying. Heat and radiation generated by the arc may enter into a reaction with vapours of solvents, which may lead to the formation of phosgene – a highly toxic gas.
- The shielding gas used during arc welding may force the air out of a room. This may lead to a health hazard or even death. Proper ventilation, especially in closed rooms, should always be provided, to ensure appropriate amount of air that is indispensable for safe breathing.

#### 1.5 NOISE CAN BE HARMFUL



In the welding environment, damaging levels of noise can exist. Continued exposure to a high noise level on the unprotected ear is injurious. The noise levels should be reduced to the lowest practicable level.

High levels may be tolerated for very short periods by wearing adequate ear protection in accordance with the national or local regulation. In case of doubt, checks by an expert should be made to establish noise levels in any particular environment, and, if these are in excess of the prescribed limit, one of the following alternatives may apply:


- a) insulation of the noise source as far as possible, e.g. by fitting silencers or sound proof enclosures,
- b) insulation of the operator from the noise

- source,
- c) effective maintenance of sound protection devices,
- d) indication as „ear protection areas“ where applicable,
- e) restriction of entry to these „ear protection areas“ to authorized persons,
- f) protect your hearing with appropriate personal protection measures, e.g. earplugs or hearing protectors.

## 1.6 FIRE OR EXPLOSION HAZARD

Arc welding and allied processes can cause fire and explosions. Precautions should be taken to prevent these hazards.

### 1.6.1 Fire hazard




- Before setting to perform welding operations, ensure that elements involving fire hazard are removed from the zone where welding operations will take place. If it is impossible, protect all flammable elements against the impact of sparks. Remember that sparks and hot metal may penetrate through small cracks and openings into the adjacent area.
- Avoid welding in the vicinity of hydraulic conduits.
- The welding arc throws sparks and splatters out. Welders should wear clean and dry protective clothing (*staining with oil should be avoided in particular*) such as welding gloves, welder's apron, welder's trousers, welder's boots, protective hood/cap, etc.
- When welding operations are not carried out, make sure that no part of the electrode comes into contact with the workpiece or protective earthing. Accidental contact may lead to overheating and create a fire hazard.
- The fire extinguisher should be ready for use and located in an easily accessible place.
- The surroundings of the work should be observed for an adequate period after its termination.
- „Hot spots“ and immediate surroundings should be observed until their temperature has dropped to normal.

### 1.6.2 Explosion hazard

It is forbidden to heat up, cut or weld tanks, barrels or containers that contained toxic or flammable materials. For there is an explosion hazard, even if the containers have been emptied and cleaned.

### 1.6.3 Use of cylinders with shielding gas



In case compressed gases are used in the work place, apply special safety measures to prevent dangerous situations.

- Use gas cylinders with appropriate shielding gas, foreseen for a particular process. Additional equipment (pressure regulator, hoses, connectors) should be in good technical condition. A gas cylinder and accessories should have the required valid attestations and approvals for use.
- Gas cylinders should always be stored in vertical position, fixed to an undercarriage or permanent support.
- Gas cylinders should be placed far away from areas, where they could be exposed to the risk of being overturned or suffering physical damage.
- Ensure gas cylinders are at a safe distance from places where electric welding or cutting operations are to be performed, away from other sources of heat, sparks or flames.
- Care shall be taken to prevent gas cylinders in the vicinity of the workpiece becoming part of the welding circuit.
- Never allow the electrode, electrode holder or any other live electric part to get in contact with the gas cylinder.
- Keep your face and head away from the


cylinder valve socket when the valve is being opened.

- Special valve shield should always be installed during cylinder transportation or when the cylinder is not used.

**1.7 OTHER HAZARDS**


Arc welding and allied processes carrying other hazards not listed before.

**1.7.1 Burns**



- Never touch hot parts with bare hands.
- Before handling an element, wait until it cools down.
- Use appropriate tools to grip and handle hot elements and wear special welding gloves and clothing that protects against burns.

**1.7.2 Plasma arc is dangerous**



Highly concentrated plasma arc poses a hazard for health and life. It is forbidden to aim plasma arc at people.


**1.7.3 Welding wire can cause injuries**



Accidental pressing of the button on the welding torch can cause welding wire to advance in an uncontrolled manner. The welding wire tip may be sharp.

Never aim the burner tip of the welding torch at your face, eyes or other people.

**1.7.4 Moving elements can be dangerous**



All protective elements and device housing should be in place and in good technical condition. Keep your hands, hair, clothes and tools away from gear wheels, fans and other moving parts during their operation.

Do not bring your hands close to fan motors. It is forbidden to stop a fan by pressing its axis.

**1.7.5 HF – high frequency ignition may cause interference**



As welding by the TIG method or plasma cutting involves high frequency ignition, it can interfere with mobile phones, radio equipment, TV equipment or improperly protected computers and industrial robots, which leads to total disabling of such devices.

**1.8 OTHER INFORMATIONS**

When performing welding work, you must apply equally to the health and safety requirements contained in the current normative acts, applicable in your country.



**WARNING!**

*The maximum voltage of 15kV. Accidental pressing of the microswitch results in unintentional arc ignition. Never bring a bare hand close to the electrode, when the device is connected to a power source.*

**1.9 SYMBOLS USED IN INSTRUCTIONS**

We use this symbol to pay your attention about important information.

**2. ELECTROMAGNETIC FIELDS (EMF)**

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). All welders should use the following procedures in order to minimize the risk associated with exposure to EMF from the welding circuit:

- Route the welding cables together – secure them with tape when possible.
- Place your torso and head as far away as possible from the welding circuit
- Never coil welding cables around your body.
- Do not place your body between welding cables. Keep both welding cables on the same side of your body.
- Connect the return cable to the workpiece as close as possible to the area being welded.
- It is forbidden to sit or lean on power source while working.
- Do not weld whilst carrying the welding power source or wire feeder.

**WARNING!**

*The electromagnetic field (EMF) generated during welding (and allied processes) may interfere with the operation of implanted medical devices for example: cardiac pacemakers. Persons with implanted medical devices such as cardiac pacemakers are obliged to consult a doctor before starting to weld/plasma cutting and to exercise special caution during work. It is forbidden for such persons to be present in the vicinity of the place where welding/plasma cutting processes are realized without previous consultation of a doctor.*

**3. ELECTROMAGNETIC COMPATIBILITY (EMC)****WARNING!**

*This Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There can be potential difficulties in ensuring electromagnetic compatibility in those locations due to conducted as well radiated radio-frequency disturbances.*

**3.1 GENERAL INFORMATIONS**

The user is responsible for installing and using the arc welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected, then it shall be the responsibility of the user of the arc welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing the welding circuit. In other cases, it could involve constructing an electromagnetic screen enclosing the welding power source and the work complete with associated input filters. In all cases electromagnetic disturbances shall be reduced to the point where they are no longer troublesome.

! *Welding and plasma cutting processes may emit additional interferences. User is responsibility for the interferences caused by welding and plasma cutting.*

### 3.2 ASSESSMENT OF AREA

Before installing arc welding equipment, the user shall make an assessment of potential electromagnetic interferences in the surrounding area. The following shall be taken into account:

- a) other supply cables, control cables, signaling and telephone cables, above, below and adjacent to the arc welding equipment,
- b) radio and television transmitters and receivers,
- c) computer and other control equipment,
- d) safety critical equipment, for example guarding of industrial equipment,
- e) the health of the people around, for example the use of pacemakers and hearing aids,
- f) equipment used for calibration or measurement,
- g) the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures.
- h) the time of day that welding or other activities are to be carried out.

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

### 3.3 METHODS OF REDUCING EMISSIONS

Methods of reducing electromagnetic interference are listed in detail in the standard EN 60974-9 – „Arc welding equipment – Part 9: Installation and use“.

## 4. CONFORMITY WITH STANDARDS

The SPARTUS® MasterMIG 200/250 PFC SYNERGY are in conformity with the relevant Union harmonization legislation:

**LVD 2014/35/UE**

Low Voltage Directive

**EMC 2014/30/UE**

Electromagnetic Compatibility Directive

harmonized standards:

**EN 60974-1**

**Arc Welding Equipment – Part 1: Welding Power Sources**

### 4.1 CE MARKING

CE marking is placed on the nameplate of device and/or on the front panel of device.



### 4.2 RATING PLATE

Rating plate and serial number are located on the device case.

## 5. GENERAL DESCRIPTION

### SPARTUS® ProMIG 200PFC

This is a professional, portable, multi-process semi-automatic welding device. It enables MIG/MAG, TIG and MMA welding with maximum welding current of 200A. The unit is powered from a single-phase network 230V.

The machine was produced with using of modern solutions such as inverter technology, IGBT power transistors, MCU controller, PWM technology, PFC filter. All of our technology solutions provide stable output performance under a variety of conditions, which has a direct effect on outstanding arc characteristics and welded joint quality. **ProMIG 200PFC** is equipped with a high-resolution digital color LCD display with an intuitive user interface. It has been programmed for maximum convenience when setting parameters. The undoubted advantage is the multilingual interface, available in languages: Polish, English, Spanish, German, French, Russian, Slovenian, Portuguese, Lithuanian, Serbian and Czech.

### MIG WELDING

#### 16 synergistic programmes

**ProMIG 200PFC** is equipped with 16 ready-made, synergistic programs for welding such materials as: steel, stainless steel, aluminum and CuSi3 brazing program. The user only selects the type of material to be welded and the diameter of the wire. Then, after setting the material thickness, the parameters adjust automatically. Additionally, it allows you to manually correct parameters.

The machine has a number of functions that support MIG / MAG welding processes:

- Wave Control – precise arc dynamics adjustment Wave control ensures full control over the welding arc: it allows to reduce the amount of welding splashes and controls the width and depth of fusion.
- Burn Back – precise adjustment of welding wire burning speed allows limit a risk of sticking the welding wire to the contact tip.
- Slow Feed –so called gentle start-up of the wire feeder, recommended especially during welding with high amperage and high speed of wire feed. Smooth start of wire feed eliminates the risk of welding defects at the beginning of the weld.
- 2T/4T – choice of one of two operating modes.

#### Manual mode

**ProMIG 200PFC** also works in manual mode. It allows you to set all welding parameters in accordance with the individual requirements of the user.

#### Spool Gun

**ProMIG 200PFC** gives possibility of welding with a Spool Gun type welding holder with a built-in wire feeder. This significantly relieves the device and increases its range, allowing you to work with welding guns longer than 5 meters.

#### Polarity change

External change of welding polarity enables welding with self-shielding wires without gas. Both with the use of a standard MIG / MAG gun as well as a SPOOL GUN.

#### Stable wire feeder

A high-quality, built-in two-roll feeder ensures stable welding wire feeding. Smooth movement during operation is essential in order to obtain a high-quality weld.

## TIG Lift WELDING

**ProMIG 200PFC** enables welding with the TIG Lift method. Thanks to the built-in solenoid valve, the device allows the use of a **TIG welding torch with a microswitch** (proposed SPP17-4-mSRP1B-X-8SPA). **ProMIG 200PFC** has a functions that support TIG welding process:

- **2T/4T operating modes**
- **Down Slop**
- **Post-gas** – gas flow after completion of welding.

## MMA WELDING

The device also allows for basic welding by the MMA method. Built-in functions to support this process include:

- Hot Start – for easier electrode ignition
- Arc Force – for easier welding in forced positions
- VRD – lower no-load voltage, increased work safety.

Compact size, lightweight and special design, make the **ProMIG 200PFC** extremely handy and easy to move.

**SPARTUS® ProMIG 200PFC** is made in accordance with the latest trends in the production of welding equipment. Compact size and technologically advanced solutions make this welding machine a perfect device for the shipbuilding industry to perform minor repairs and renovations. It is also used in widely understood workshop works, light production works and in the automotive industry – car body repairs: welding and CuSi3 brazing, welding of exhaust systems.

### 5.1 PURPOSE OF USE

SPARTUS® ProMIG 200PFC is designed for:

- Metal Inert Gas (MIG) / Metal Active Gas (MAG) welding (MIG/MAG),
- Tungsten Inert Gas welding (TIG),
- Manual Metal Arc (MMA) welding (GMAW – Gas Metal Arc Welding; SMAW – Shielded Metal Arc Welding).

## 6. TECHNICAL SPECIFICATIONS

### 6.1 OPERATION, STORAGE AND TRANSPORT

#### Conditions during operation, storage and transport

Range of ambient air temperature during operation	-10°C to +40°C
Relative humidity of the air	up to 50% at +40°C up to 90% at +20°C
Ambient air	free from abnormal amounts of dust, acids, corrosive substances etc. other than those generated by the welding process
Base of the welding power source inclined	no more than 10°
Range of ambient air temperature during storage and transport	-20°C to +55°C

**Duty cycle (def.)**

Duty cycle is the time during which You can weld or cut at a certain load without causing overload. It is expressed in percent for period of complete cycle which equals 10 minutes. For example: 60% duty cycle means that for 6 minutes device can operate at given load, after that required 4 minutes time break (no-load operation). Duty cycle is given to ambient temperature of 40°C.

**Protection against overheating (def.)**

Security system from overheating will turn on when the welder is over-heat (possibility of welding is turned off, abnormal indicator on front panel lights up). In such a situation, You should not turning off the unit immediately. Wait some time until fan cools the unit. Time to return to the state from overheating can take up to approx. 15 minutes.



The device has a degree of protection IP23. Which means that it is intended to be used in closed and covered areas and suitable for use outdoors. However it is not designed to be used outdoor during precipitation if it is not covered.

**6.2 TECHNICAL PARAMETERS OF DEVICE****ProMIG 200PFC**

Input	~1 x 230V ± 10% 50 / 60 Hz
Welding current MIG [A]	25 – 200
Duty cycle MIG [%]	40

**MIG PARAMETRS**

Output working voltage [V]	15.3 – 24
Wire feeder type	built-in, 2-roll gear
Wire diameter Ø [mm]	0.6 / 0.8 / 1.0
Wire feeding speed [m/min]	1.5 – 13
Welding wire spool [mm]	≤ 5 [kg], Ø200
CuSi3 brazing	✓
Inductance control	✓
Slow feed	✓
Burn Back	✓
2T / 4T control	✓
Pre-gas [s]	0 – 2
Post-gas [s]	0 – 10
Spool Gun	✓

**TIG PARAMETRS**

TIG DC welding	✓
Welding current TIG [A]	10 – 200
Duty cycle [%]	40
Down slope [s]	0 – 10
Post-gas	✓

2T / 4T control	✓
Arc ignition	LIFT

## MMA PARAMETERS

MMA welding mode	✓
MMA welding current [A]	10 – 200
Duty cycle [%]	40
Arc Force regulation	0 – 10
Hot Start regulation	0 – 10
VRD	✓
No-load voltage [V]	67

## OTHER PARAMETERS

PFC filter	✓
Max. current consumpition [A]	MIG 25.4 / MMA 28.8 / TIG 20
Power factor (cosφ)	0.99
Efficiency η [%]	85
Insulation class	H
Protection class	IP21S
Weight [kg]	16.4
Dimensions [mm]	600 × 210 × 410

## 7. INSTALLATION AND USE



### WARNING!

*SPARTUS® ProMIG 200PFC is intended for professional and industrial applications. Installation and use of the device may only be carried out appropriately trained professionals.*

*It is **forbidden** to carry out work related to metalworking (for example grinding, drilling, etc.) near the welding device, especially near the vents. Sparks and metal shavings may penetrate the inside of device, which can lead to failure or damage of welder.*



### Qualified person (def.)

*A person who has gained the relevant technical education, training took place and / or gained experience to perceive the risk and avoid hazards during use of the product (IEC 60204-1).*

### 7.1 PROPER COOLING


Unit should stand stable on dry and level surface. Avoid too much slope and slippery surfaces. Regularly check that the vents (inlet, outlet) are not covered. The minimum distance between the welder vents and walls should be 50cm.

### 7.2 MOVEMENT AND HANDLING

Please take special care when moving the welding machine. The device should be moved by using specially designed transport lugs. If transport handle is damaged, then it needs to be repaired at an authorized service center.

## 7.3 DESCRIPTION OF CONSTRUCTION

### 7.3.1 Front panel / rear panel



① Transport handle

② SK socket, „+“

③ Polarity change power connection

④ Gas connector for TIG torch

⑤ Control plug socket

⑥ SK socket, „-“


⑦ EURO socket – MIG gun connector

⑧ Toggle switch ON/OFF

⑨ Gas connector

⑩ Power cable

### 7.3.2 Inside / wire feeder



- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>⑪ Fixing mechanism for welding wire with fixing nut</li> <li>⑫ Feeder's rolls pressure adjustment knob</li> <li>⑬ Welding wire guide<br/>– input of the guide</li> </ul> | <ul style="list-style-type: none"> <li>⑭ Wire feed tension arm</li> <li>⑮ Wire drive roller</li> <li>⑯ Spool Gun function switch</li> </ul> |
|---|---|

## 7.4 CONNECTING TO POWER SUPPLY

Requirements for power network parameters (voltage, permissible range of mains voltage fluctuations etc.) are given in the table with technical parameters of device and on the rating plate of welding machine.

### Before connecting the unit to the power source:

- Check whether the parameters comply with the requirements for unit.
- Check: mechanical condition of the power cord and plug. The connection status of the power cord with plug and unit (loose not allowed). If the power cord or plug is damaged or loose connection is between them, it is forbidden to connect the welder until fault has been rectified.
- The machine can be connected to the network only when the power socket is properly grounded.

## 7.5 INSTALLATION – MIG WELDING



Before connecting hardware and shielding gas to the device, make sure that the device is disconnected from power source and switch ⑧ is in the OFF position.

### 7.5.1 Connecting the gas cylinder

1. The cylinder with appropriate shielding gas, should be placed in a vertical position and secured against falling over in accordance with safety requirements (*for gas cylinders under the influence*).
2. Make sure that the valve cylinder is closed.
3. Connect properly gas regulator to cylinder valve.
4. Connect the gas hose into gas regulator outlet. Secure the connection with a special clamp.
5. Connect the gas hose to the socket in the machine ⑨.



The valve in the cylinder must be opened immediately before welding. After welding it should be closed.

### 7.5.2 MIG/MAG gun installation

1. Connect properly MIG gun plug to EURO socket ⑦ to the machine.
2. Pay special attention to the correct fit of the control pins and input welding wire from wire feeder to the wire inlet guide in MIG gun.
3. Tighten the MIG gun plug nut clockwise until it stops. Incorrectly mounted MIG gun can cause damage.






### 7.5.3 Assembling welding wire into liner

1. Connect properly MIG gun into welding machine (see 7.5.2).
2. Dismantle the torch consumables (*gas nozzle, contact tip*).
3. Connect the welder into power supply. Turn on the machine using power switch **8**.
4. Expand MIG gun as straight as it is possible.
5. Hold the microswitch on the welding gun and start wire feeding into MIG gun liner. Make sure that pressure tension of feeder rolls is suitable. Remember! Never point torch into direction eyes / face or others.
6. When wire end comes out to a distance approx. 30mm beyond the torch outline, release microswitch.
7. Assemble welding wire into liner (*gas nozzle, contact tip*).
8. Cut off the end of wire properly.

### 7.5.4 Device installation (for wire welding with gas shielded)

1. Connect the gas hose to the device (see 7.5.1)
2. Connect MIG gun into device (see 7.5.2)
3. Connect return cable into SK socket „-“ **6**, and the earth clamp into workpiece. Ensure that all threaded connections do not have any slack, and gas connection is tight.
4. Connect the welder into power supply in accordance with appropriate guidelines (see 7.4)
5. Turn on the machine using power switch **8** in the ON position.
6. Device is ready to weld.




### 7.5.5 Device installation (for wire welding without gas shielded)


1. Connect MIG gun into device (see 7.5.2)
2. Connect return cable into SK socket „+“ **2**, and the earth clamp into workpiece.
3. Insert the polarity switching cable plug into SK socket „-“ **6**
4. Connect the welder into power supply in accordance with appropriate guidelines (see 7.4)
5. Turn on the machine using power switch **8** in the ON position.
6. Device is ready to weld.

### 7.5.6 Installation & operation for SPOOL GUN

1. Insert the earth cable plug into the SK<sub>,-</sub> socket (6) on the front of the machine and twist to tighten.
2. Insert the polarity switch cable plug into SK<sub>,+</sub> socket (2) on the front of the machine and tighten it.
3. Plug the Spool Gun into the euro connect socket (7) on the front panel and tighten. **IMPORTANT:** When connecting the torch be sure to tighten the adaptor nut completely tight. A loose connection can result in arcing between the gun and machine connector and that causes serious damage to both the torch and machine connections.
4. Connect the Spool Gun control cable to the socket (5) on the front panel.
5. Connect the gas regulator to the gas cylinder and connect the gas line to the regulator.
6. Connect the gas line to gas connector (9) on the rear panel.
7. Connect the power cord of the welding machine to the power source and turn on (16) Spool Gun switch.
8. Remove the spool cover by pressing button and lifting off the cover.



9. Place a spool of wire inside the spool holder on post.



10. Feed the wire through the drive rolls and into the inlet guide tube. Tighten the wire tension swing arm.



- Pull the trigger to drive the wire down the neck until it exits the contact tip.



- Carefully open the gas cylinder valve and set the required gas flow rate.
- Set welding parameters using the knobs as shown on digital displays.

## 7.6 INSTALLATION – TIG WELDING



Before connecting hardware and shielding gas to the device, make sure that the device is disconnected from power source and switch **8** is in the OFF position.

### 7.6.1 Connecting the gas cylinder


- The cylinder with appropriate shielding gas, should be placed in a vertical position and secured against falling over in accordance with safety requirements (for gas cylinders under the influence).
- Make sure that the valve cylinder is closed.
- Connect properly gas regulator to cylinder valve.
- Connect the gas hose into gas regulator outlet. Secure the connection with a special clamp.
- Connect the gas hose to the socket in the machine **9**.



The valve in the cylinder must be opened immediately before welding. After welding it should be closed.

### 7.6.2 TIG torch installation

- Connect properly TIG torch plug to SK socket „-“ **6**.
- Connect properly TIG torch control plug into control socket **5**. Pay attention to suitable fitting of control pins.
- Connect gas hose into shield gas connector at the front panel **4**.



## 7.7 INSTALLATION – MMA WELDING




Before connecting hardware and shielding gas to the device, make sure that the device is disconnected from power source and switch **8** is in the OFF position.




The welding polarity depends on the type of electrodes used. Before connecting the cables refer to the requirements specified by the manufacturer of electrodes.

1. Connect electrode cable plug into SK socket according to the welding polarity **6** or **2**.
2. Connect return cable plug into SK socket according to the welding polarity **6** or **2**.
3. Connect earth clamp into workpiece.
4. Connect the machine into power supply in accordance with guidelines (see 7.4).
5. Turn on the device by setting power switch **8** in the ON position.
6. The device is ready to weld.



## 7.8 DEVICE CONTROL PANEL – USING


### 7.8.1 Control panel description



- (AP) Screen selection – menu  
 (BP) Parameters approval  
 (PL) Selection/parameter adjustment knob  
 (PP) Selection/parameter adjustment knob  
 (EP) Colour LCD display

## 7.9 USER INTERFACE USING


### (AP) WELDING METHOD SELECTION



- (M1) Welding method selection  
 (M2) MIG/MAG synergic programme selection  
 (M3) Additional functions for chosen welding method  
 (M4) User interface settings

### (M3) MIG/MAG – ADDITIONAL FUNCTIONALITIES FOR MIG/MAG WELDING MODE


1. (PL) – parameter selection
2. (PP) – parameter value selection
3. (PP) or (PL) – parameters approval



<b>2T / 4T</b>	one of two operating modes 2T / 4T
<b>Burn Back</b>	precise adjustment of welding wire burning speed allows limit a risk of sticking the welding wire to the contact tip
<b>Slow Feed</b>	so called gentle start-up of the wire feeder, recommended especially during welding with high amperage and high speed s of wire feed. Smooth start of wire feed eliminates the risk of welding defects at the beginning of the weld
<b>Pre-flow</b>	gas flow speed before arc ignition
<b>Post Flow</b>	gas flow speed after welding
<b>Inductance</b>	precise arc dynamics adjustment Wave Control ensures full control over the welding arc: it allows to reduce the amount of welding splashes and controls the width and depth of fusion

**M3 TIG – ADDITIONAL FUNCTIONALITIES FOR TIG WELDING MODE**


1. **PL** – parameter selection
2. **PP** – parameter value selection
3. **PP** lub **PL** – parameters approval



<b>2T / 4T</b>	one of two operating modes 2T/4T
<b>Pre-flow</b>	gas flow speed before arc ignition
<b>Down Slope</b>	current falling speed
<b>Post Flow</b>	gas flow speed after welding

**M3 MMA – ADDITIONAL FUNCTIONALITIES FOR MMA WELDING MODE**

1. **PL** – parameter selection
2. **PP** – parameter value selection
3. **PP** lub **PL** – parameters approval

**Hot Start**


easier electrode ignition in MMA welding mode thanks to temporary increase of welding current amperage during arc ignition attempt

**Arc Force**

arc dynamics adjustment, easier welding in forced positions  
i.e. overhead position

**M4 INTERFACE PARAMETERS SETTINGS**

1. **PL** – parameter selection
2. **PP** – parameter value selection
3. **PP** lub **PL** – parameters approval

**Language**

interface language version selection

**Unit**

unit selection

**Beeper**

(On/Off) enable or disable interface audio

**Brightness**

LCD brightness adjustment

**Factory reset**

restore factory settings

**7.9.1 MIG / MAG parameters setting – SYNERGIC MODE**

1. **M1** – mode selection: **MIG/MAG Synergic**
2. **M2** – synergistic programme selection and confirming the selection **PP** lub **PL**


## M2 LIST OF SYNERGISTIC PROGRAMMES

PRG	MATERIAL	GAS	D
01	Fe-metal Solid-cored	CO2	0.6
02	Fe-metal Solid-cored	CO2	0.8
03	Fe-metal Solid-cored	CO2	0.9
06	Fe-metal Solid-cored	CO2	1.0
05	Fe-metal Solid-cored	CO2	0.6

01 Fe-metal Solid-cored CO2 D=0.6mm

### 7.9.2 Setting the MIG / MAG SYNERGIC welding parameters

1. **PL** – welding current value setting
2. **PP** – welding voltage correction
3. **PP** lub **PL** – parameters approval




Additional welding parameters are set in the **M3** MIG/MAG screen

### 7.9.3 MIG / MAG parameters setting – MANUAL MODE

#### M1 mode selection: MIG/MAG MANUAL

1. **PL** – welding current value setting
2. **PP** – welding voltage correction
3. **PP** lub **PL** – parameters approval






Additional welding parameters are set in the (M3) MIG/MAG screen

#### 7.9.4 TIG parameters setting

##### (M1) mode selection: TIG


- (PL) – welding amperage value setting and parameters approval



Additional welding parameters are set in the (M3) TIG screen

#### 7.9.5 MMA parameters setting

- (PL) – welding amperage value setting and parameters approval



Additional welding parameters are set in the (M3) MMA screen

## 8. MAINTENANCE

### WARNING!

Before performing any maintenance or repairing of device, disconnect welding machine from the power source and wait at least 5 minutes. The voltage accumulated in capacitors should be discharged at this time to a safe level. But even after that operation you should be careful.



Make sure that the device is disconnected from the power source, and switch **8** is in the OFF position, before connecting accessories and shielding gas to the device.

Maintenance and repair work may be performed only by qualified personnel with the appropriate permissions. Regular maintenance provides adequate service life and trouble-free operation of the device.

### Routine maintenance (daily: before use/installation):

- Perform a visual inspection of the housing, knobs, control panel.
- Inspect (visual inspection) the power cord and power plug. Check the insulation of the cable.
- Check the condition of welding cables and their connectors. If cable insulation is damaged – replace it. If connection is too loose – eliminate backlash.
- Check if cooling fan is working properly.
- Make sure that all vents are not obstructed.


### At least once a month:

- Regularly remove dust from inside of the machine. Use for this compressed air. The pressure should be sufficiently low so as not to damage small components inside the machine. If in the workplace, dust levels are high. You should clean machine often.
- Perform inspection of connection of internal electrical components. If anywhere the joints are loose, tighten them.

### Once a year:

- You should send device to an authorized service center for an interim review.

## 9. ENVIRONMENTAL PROTECTION



The product must not be disposed of into an ordinary waste container. It is totally forbidden to dispose of electric or electronic equipment marked with a crossed-out trash can symbol by throwing it into ordinary waste containers. According to the WEEE directive (directive 2012/19/UE), binding within the European Union, such products should be disposed of according to local regulations.

We hereby inform the client that, according to the regulations, each commodity is burdened with waste disposal costs (WDC) according to charging rates valid for a given year.

## 10. TROUBLESHOOTING



Not all problems with functioning of the device, are the evidence of failure. You can independently carry out an analysis in search of probable failure. In case of doubt, please contact to SPARTUS® dealer or authorized service center.



During the warranty period all repairs should be carried by authorized service center. Repairs carried out by unauthorized persons will void the warranty.

### PROBLEMS WITH THE DEVICE

After turning ON the switch the device does not correspond

Poorly connected to the supply voltage  
Failure of power switch

### PROBLEMY ZE SPAWANIEM MIG

No arc

No power supply  
A break in circuit welding  
A break in the control circuit

Excessive heating of MIG gun

Contact tip is not properly fastened or tightened  
Too high welding current in relation into MIG gun capacity

Unstable wire feeding

Blocked guide wire (liner)  
Worn contact tip  
Contact tip diameter is not suitable to wire diameter  
Wrong adjustment of tension pressure of rolls

Unstable arc welding

Contact tip is worn or its diameter is incorrect  
Incorrect welding parameters  
Worn liner

### MMA WELDING PROBLEMS

Arc ignition problem

Incorrect connection of return cable or there is no connection of return cable  
Too low welding current

Excessive spatter welding.  
The problem with the arc ignition

Incorrect welding polarity

Unstable arc, excessive spatter welding,  
poor weld quality

Incorrect welding polarity  
Electrode is damp or incorrectly heated  
Unstable voltage in

No load voltage equals 0V

Damaged device

*TIG WELDING PROBLEMS*

The problem with TIG arc ignition	Damaged microswitch
	Control plug is not connected. Problems with control plug
No gas flow	Closed valve in the gas cylinder, a closed valve in the gas pressure regulator. Clogged gas hoses leading the gas to the device.
	Electromagnetic valve is damaged
After switching on the device gas flows all the time	Electromagnetic valve is damaged
The problem of obtaining adequate weld penetration	Too low welding current
Poor quality of weld	Improper welding parameters
	Too little flow of the shielding gas or its quality is inadequate
	Excessively worn of tungsten electrode
<i>OTHER</i>	
Protection mechanism started Against overheating	Too much welding amperage. Exceeded operation cycle.
Lights an abnormal indicator. Overheat protection is on.	Excessive welding current. Exceeded duty cycle.

## Notes

---

## Notes

---




**EASY**

*Simple solutions and an attractive price – these are the features of SPARTUS® Easy series devices. Our equipment has been designed with ease of use and ergonomics at work in mind.*

*A masterly combination of high quality production, excellent parameters and ergonomics – these are features of the SPARTUS® Master series of devices, which were created with demanding welding jobs in mind.*



**MASTER**



**PRO**

*Precision, functionality, excellent parameters and resistance to high workloads – these are the features of the SPARTUS® Pro industrial series of devices. This series consists of specialised solutions which will satisfy even the most demanding users.*



Videopresentation of products



Subscribe to the channel **SPARTUS.INFO**